



ECU Home Screen

Startup Screen



If you open the software without a live device connected, you will come to the main pallet or screen which forms the framework of the Hyperspace software. It looks the same for all the devices. From here you can open map files, connect to devices and set basic settings required for the software to operate.



Once you connected to a Device you will get a screen like this.

Top Toolbar




Like any Windows program you will find standard menus and buttons which relate to program settings and preferences. Offline Map files could also be selected and edited with the file button.

Notice the Version and Date in the name. this will help dealers to see if you have the latest software installed. Make sure from time to time that you have the latest version which is free from our website. Especially if you find something in the software that may function incorrectly. We fix these errors immediately and replace the version on our website.

This software is Version 3.6.1 The last 1 is a sub release as fixes etc. are made. 2020-08-06 17:20:54 is the date and time this version was released


Tuning Menu




Settings is to set up units, software and device communications and auto map save settings. **Exit** is to quit the software.

Connect is to connect or dis-connect to the ECU,

Settings



Unit selection




Select Metric or Imperial units.

Language

Select Language if it is available.


Matrix Mode




Select the RPM Axis you prefer for matrix tuning.

Styles

Custom your own tuning pallet to suit the collars and font size that works for you. Remember these settings is saved in the Config file. If you upgrade versions, then rename your Config file to carry your settings over.



Device Settings




Max Poll error count:

This is the time it takes to read the real time values from the device via the Blue Tooth serial port. Blue tooth communication is not as smooth and fast as USB communication. It requires a tolerance setting to ignore short intervals of no communication. Increase this value till the flashing LED stops flashing RED. For USB cables keep this value at 0.

Blue Tooth Delay

This setup will add a delay that some blue tooth modules will require to operate. Leave it at zero if not used.


Save Settings



The 'Save Settings' dialog box contains a 'Save' button on the left. On the right, there are two settings: 'Auto Save Every' set to 10 minutes and 'Maximum List Size' set to 10 files. Both settings have up and down arrows for adjustment.

The software will do **Auto saves** at time intervals. The intervals can be adjusted here. It will also have a max display list on the open file menu. Then the software will also make a backup copy of each download to ECU and it is called **Device Saves**. File location for these maps is in the folder where the Hyperspace is saved on the hard disk.

Hotkeys



The 'Hotkeys' settings window has a sidebar with icons for General, Styles, Device, Save, Hotkeys, and Close. The main area has tabs for Application Keys, Graph Keys, Matrix Keys, and Data Logger Keys. A note states: 'To change a hotkey or remove the key, right click on the selected key and select an option from the dropdown menu. Bold keys can not be changed!'. Below this is a table of hotkeys.

Description	Action Key	Primary Key	Secondary Key
Enables or disables realtime tuning	None	R	Not Assigned
Enables or disables mouse tuning	None	M	Not Assigned
Enables or disables easy tuning	None	E	Not Assigned
Show or hide all lines on maps	None	H	Not Assigned
Enable or disable Initialise tuning	None	I	Not Assigned
Clear real time errors	None	C	Not Assigned
Close the application	None	F4	Not Assigned
Toggle between available lines in the chart	None	T	Not Assigned
Set the digital selection	None	D	Not Assigned
Switch to next control/Switch between graphs on same page	Ctrl	Tab	Not Assigned
Save	Ctrl	S	Not Assigned

A 'Reset to defaults' button is located at the bottom right of the window.

These settings let you customise quick keyboard keys to fast track moving between screens and functions. They are completely customisable. In the factory we will set up basic keys for your

convenience. You may restore to default when you chose to. Remember these settings is saved in the Config file. If you upgrade versions, then rename your Config file to carry your settings over.

Close Button




Close will save your selections in the Config file and go back to the tuning pallet.

Device




Assign Device

For your convenience Assign Device is built into the Hyperspace Tuning Software. If a system is upgraded or activated on the Portal, the customer only need to have internet connection to activate his system. When you click Assig and there is an active allocation on the Portal, this message will appear:



Click Yes and the device will be activated.

If there is no allocation change on the Portal, then the following message will appear:



Load Device Firmware

Mercury2 still use the USB Debug Adapter to load firmware. This message will not be visible. See that section in another document.

Orion2 and Venus3 have a built in bootloader and you may load firmware from the Hyperspace tuning software. This firmware is only saved on the Internet so you will have to have a live internet

connection. Click on Load Device Firmware and a browser will come up. Select your firmware file to load and click open. First the Type of firmware then the Version of firmware then the Firmware number that is required.

Firmware

Please select the relevant firmware that you want to load to the unit in the list below.

Hardware Type

ECU

Version

3.6

Firmware


Orion2 ECU Combo 28 60-2 4Cyl Ver 3.6B 18_06_2021.OTfirm

Cancel

Ok

Press OK and this warning will come up.

Confirmation



You are about to write the file (Orion2 ECU Combo 28 60-2 4Cyl Ver 3.6B 18_06_2021.OTfirm) to the connected device.

PLEASE DO NOT TURN THE POWER OFF UNTIL THE BOOTLOADER IS FINISHED! CLOSE ALL SPITRONICS AND ECU/TCU PROGRAMS THAT MAY INTERFERE WITH THE COMPORT. THEY MAY CORRUPT THE DOWNLOAD ROTINE.

Are you sure you want to continue?

Yes

No

Press Yes and do not switch the power off until the next 2 messages appear.

Hyperspace ECU V3.6.10 2022-01-21 19:00:00

Device Information

ECU Setup

Timing Graph

Fuel Graph

Lambda Graph

Water Graph

Voltage Graph

Device Information

Device Serial Number

Hardware Type

Hardware Class

Firmware Type Loaded

Firmware Number Loaded

Brand Code


Firmware Loaded Information

Firmware Type

Firmware Number

Firmware Class

Firmware Version



Writing firmware to device. Please do not switch the power off!

Lambda 0 %

Map 0.00 Bar

Injector 0.0 ms

Inj. Duty 0 %

TPS 0 %

POT 0 %

0 RPM

WATER

0 °C

BAT

0.0 v

No device connected


Bootloader present

Mobile - Yes

Device Map

Uploading firmware...

Count: 5 (Code 6 - Information: Engine stopped. No pulses)



Now you have successfully loaded new firmware in the device. You can now reset all the settings according to the new engine.

Note: Should there be any bug fixes it will be loaded under the same name. So always start with the latest firmware loaded from the web and see if your issue has not been fixed already. Jst load the same file in again.

Pin Layouts

This feature will allow you to export the setup of Orion2 connection to an Excel spreadsheet. It will ask you to enter a File name and folder in a browser where to save. Below is an example of such a layout.


Orion2 In/Out Layout					
Output Name	Pin Name			Pin Name	Output Name
P1 - 12 Way Input					
	Water Temp	7	1	Air Temp	
	Lambda	8	2	TPS	
	+.5 Volt Out	9	3	MAP	
	+.12 Volt Ign	10	4	GND	
	TDC Sensor	11	5	TDC Power	
	Crank Sensor	12	6	Crank Power	
		Internal		3Bar Alt Sensor	
P2 - 10 Way Output					
Coil Driver 1	Coil Negative 1	6	1	Coil Negative 2	Coil Driver 2
GP 5 Output	Coil Negative 3	7	2	Coil Negative 4	GP 6 Output
Injector Driver 2	Negative 2	8	3	Negative 1	Injector Driver 1
RPM Output	Negative 4	9	4	Negative 3	Relay Out
GP 2 Output	Negative 6	10	5	Negative 5	GP 1 Output
P3 - 8 Way Output					
	Positive 1	5	1	Positive 2	
GP 7 Output	Positive 3	6	2	Positive 4	GP 8 Output
	+.12 Volt In	7	3	+.12 Volt In	
GP 9 Output	Coil Negative 5	8	4	Coil Negative 6	
P4 - 4 Way Serial					
	SDA	3	1	SCL	
	+.5 Volt Out	4	2	GND	
6 Way USB/Input					
	Tuning POT	4	1	Dual Map Switch	
	Receive	5	2	Transmit	
	+.5 Volt Out	6	3	GND	

This will tell the customer where all his connections are on the Orion2. Note that this is still Phases and not actual firing order. For that you must fill in the blocks on the respective drawings. This Layout can then be pasted in a wiring Template that look like below.

Wire Colors		(Paste Here)		Orion2 4Cyl Layout		Wire Colors	
		Sim		Pin Name	Pin Name	Sim	
	E24 CR-Only	E22 CR+TDC	leds	P1 - 12 Way Input		E24 CR+TDC	E24 CR-Only
	Green	Green		Water Temp 7	1 Air Temp	Yellow	Yellow
	Red	Red		Lambda 8	2 TPS	Blue	Blue
	Red	Red		.+5 Volt Out 9	3 MAP	Blue	Blue
	Red	Red		.+12 Volt Ign 10	4 GND	Black	Black
	N/C	Yellow		TDC Sensor 11	5 TDC Power	Blue	N/C
	Blue	Green		Crank Sensor 12	6 Crank Power	Red	Red
				Internal	3Bar Alt Sensor		
E33 Adv	E32 Std	E31 No Rel		P2 - 10 Way Output		E31 No Rel	E32 Std
Black/Red	Black/Red	Black/Red	N5	Coil Negative 1	6 1 Coil Negative 2	N6	Black/Purple
Black/Brown	N/C	Black/Brown	N7	Coil Negative 3	7 2 Coil Negative 4	N8	Black/Orange
Black/Yellow	Black/Yellow	Black/Yellow	N2	Negative 2	8 3 Negative 1	N1	Black/White
Green	Green	Green	RPM	Negative 4	9 4 Negative 3	Relay	Blue/Black
Blue/White	Blue/White	Blue/White	N4	Negative 6	10 5 Negative 5	N3	Blue/Orange
				P3 - 8 Way Output		E36	
		Red/White	P1	Positive 1	5 1 Positive 2	P2	Red/Yellow
		Red/Orange	P3	Positive 3	6 2 Positive 4	P4	Red/Green
		Red		.+12 Volt In	7 3 .+12 Volt In		Red
		White	GP1	Coil Negative 5	8 4 Coil Negative 6	GP2	Blue
				P4 - 4 Way Serial			
				SDA 3	1 SCL		
				.+5 Volt Out 4	2 GND		
				6 Way USB		USB	
P05-P3	USB			Tuning Pot 4	1 Dual Map Sw	USB	P05-P3
Green	N/C			Receive 5	2 Transmit	N/C	Yellow
Yellow	Yellow			.+5 Volt Out 6	3 GND	Green	Green
Red	Red					Blue	Blue

This Pin-Out can then be pasted in the wiring Template that look like below.

File Menu



This menu is to open the different saved maps or to save a map from a device onto the pc. The software will save periodic files in Auto Saves folder and also when you do a Device save it will make a copy in the *Device Save folder*.

Open is to open Map files offline

Open Recent is to open the last previous map files


Auto Saves is to open the last auto saved files

Device Saves is to open the last device saved files

Save is to save Map files on the PC

Save As is rename Map files on the PC

Help Menu



This menu holds information.

About


About will indicate all the release fixes and changes between versions released.

Manuals

It also unlocks the embedded manual and will save a copy of it in the Hyperspace folder where the software was saved initially.

Check for Updates

You may also update the software from this menu. If it is up to date then this message will appear.



ECU Toolbar



ECU Toolbar Shortcut Buttons guide you to basic operations. Some buttons have a keyboard hotkey to make it easy to activate them. The hotkey is in the title block of each button description. Green background means activated on some of them.

Hide button - H




This button is used to show all lines on a graph or hide the ones that is not selected. It is handy if graphs are on top of each other to see each one separately.

Easy tune - E



This is a very handy feature if you have to lift graph dots simultaneously. There are different algorithms. That will only move dots from the tuning bar.



Initialise will make the whole line the same value as where the green tune bar cross
When easy tune is on then SHIF-Z will initialise every dot with the same selection to the same value
as the bar.

Mouse on - M



This is handy to use mouse tuning on the graphs or disable it for arrow tuning.

Real-Time tracking - R



This is a very handy tool to move the green tuning bar with the real time bar of a graph. It is used with or without Easy Tune to adjust the same value that the device use at that time.

Data Logger



This feature is used for logging signal and tuning on the road.

Connect Button



This indicates if the unit is connected. If you click on it then it will toggle to the other option.

Map Lock Option



This is handy to lock tuning maps so that the customer cannot change parameters. It is also a feature to clone the device with calibrations from another device. *See the sub folder for explanation on its operation.*

Open Map file



This is to load a Map file from the hard disk into the device.

Save Map file



This is to save a Map file from the device onto the hard disk.

Save to device



If you made changes you can save them permanently in the flash with these buttons. You can also press CTRL-S for save or click on the yellow flashing LED.

Upload device memory



This is used with the simulator and when firmware is flashed to the device. It will refresh the software with restarting it.

Quit button



Enough said

Communication LED




This indicates the status of the device.

Flashing green means the device flash memory and PC memory are the same. No save is required.

Flashing yellow means you have changed parameters in the device but you have not made them permanent by saving to the flash memory.

Flashing red means no communication to the device.

Device Information



The device information screen displays vital information regarding the Spitronics ECU that has been connected. Note: Firmware is the program that is loaded into the ECU to make the electronics operate in a specific way. This is normally Firmware file which is loaded into the product by a USB

debug programmer or BootLoader. Software is the tuning interface that runs on the computer and it is used to tune the product's parameters.

Device Information

Device Serial Number

There is a unique number assigned to each product. It is saved on maps and recognized by the database on its status etc.

Hardware Type

Displays which type of device has been connected to the software. In this case and an Orion2 Engine Control Unit.

Hardware class

Displays the Hardware class of the product that has been connected to the software. The hardware class will determine which firmware can be uploaded onto the product. This feature allows the unit to open certain or all functions of the electronics. The amount of features determines the price of the unit. This feature can be changed over on the internet to allow for remote upgrades of the unit. The hardware classes are as follows:

1. Micro
2. Basic
3. Standard
4. Intermediate
5. Advance
6. Ultimate
7. Commercial
8. Racing

Firmware Type Locked

This block will indicate which type of firmware are allowed on the unit. If it indicates ***No Restriction***, it means that any Type of Firmware for Orion2 can be programmed into the unit like ECU, TCU TxW etc. This feature is for sponsored units or specials which was approved by the manufacturer.

Firmware Number Locked

This block will indicate which firmware number in the firmware range are allowed on the unit. If it indicates ***No Restriction***, it means that any firmware number for Orion2 can be programmed into the unit. This feature is for sponsored units or specials which was approved by the manufacturer.

Brand Code

This represent a specific brand like Spitronics which is 1. Orion2 may also be rebranded to large distributors which means this code will change. Once a brand is changed the unit will only connect to the software of that brand. This will bring exclusivity to that brands customers.

Firmware Loaded Information

Firmware Type

This block will indicate which type of firmware are loaded on the unit like ECU, TCU TxW etc.

Firmware Number

This block will indicate which firmware number is loaded and a short description.

Firmware Class

Displays the class of the firmware that has been downloaded onto the device. Each firmware program supplied will have a certain class according to the features used. You may load any firmware for a specific product into the unit as long as the firmware class does not outrank the hardware class of the Orion2. The firmware classes are as follows:


1. Micro
2. Basic
3. Standard
4. Intermediate
5. Advance
6. Ultimate
7. Commercial
8. Racing

Firmware Version

This block displays the software version as well as the firmware version that is loaded into the Orion2. In the example 3.6 is the software version which is required to communicate with the Orion2 and A is the firmware version.

The firmware version no effect on the software version. Always use the latest versions available.

Hyperspace Software Version

 Hyperspace ECU V3.6.1 2020-07-27 18:29:18


On the top bar you will find the product software version. Note that version 3.6 will be standard with the Firmware version 3.6.

The first 3 is version 3 PC Software.

The second 6 is the protocol version between the PC software and the firmware. When new features are programmed into the unit, this protocol version will change in the PC software and in the Firmware.


The .1 at the end is a sub version and has no effect on the firmware. This version will indicate corrective or improved PC software. Always use the latest version available.

Real-Time Display



This block displays all the analogue sensor values as they change in the ECU. You may change the appearance of some of the signals as well as the colors in the settings tab. Double click on certain fields will toggle between 2 types of views. Below is a description of the meaning of each signal.

Lambda Sensor



This is the Lambda sensor value displayed in %. Notice on the graph that the rich and lean is inverted between wideband and narrowband.

MAP Sensor




This value displays the manifold pressure and is scaled according to the MAP range setting.

Injection Time



This value displays the total injection time that is applied after all calculations are done. It is in 0.1 milliseconds resolution.

Injection Duty



This value displays the ratio of injection time to revolution time in %.

TPS Sensor



This value displays the throttle position opening in %.

POT Sensor



This input can be connected to a potentiometer or other connections to achieve functions like launch control etc.

RPM





This value indicates engine revolutions per minute.

Ignition Timing



This value displays the total ignition timing that is applied after all calculations are done. It is in 1 degree's resolution.

Water Temperature Sensor



This value displays the current engine water temperature.

Altitude Sensor



This value displays the altitude pressure of your location.

Fuel Pressure Sensor



This value displays the fuel pressure in the header.

Air Temperature Sensor




This value displays the current air temperature at the air intake.

Battery Voltage




This value displays battery voltage that is connected to the ECU.



Status Bar Display




This block at the bottom of the software displays all kinds of status, information and fault codes. Below is a description on types of messages.



When no device is connected, the connection button may be open and an indication that no device is recognized. If you use a different USB cable, you may need to click on the connect button to tell the software to search other Comms ports as well. Once a port is found with a recognized device the software will lock onto that port to minimise start up times. It will then display the device type and COM port as below.



At bottom right corner is connection information. This will indicate which Comms Port is being polled for a device. If you have changed the USB cable to another one, then this Comms Port may not be the Port number that the software remembered. Click on the Connect button then the software will look on all the available Ports for a device. Once a device is found, this will be saved in the Config file to cut down on start time for the next connection.



Orion2 has a BootLoader to load firmware. This indication will show if it is active on that device.





This message indicates if the unit is mobile software capable or not. Some mobile applications will run only if this is set. Contact your supplier for activation.










Save was successful.

The software will also give occasional indications on tasks like if the map was saved successful or not.

 Count: 4 [Code 1 - Error: Missing crank pulses]

This message will indicate Errors, Warnings and Information. This is helpful to the user to find errors in the setting up of the device. If you click on the  button left of the error, a list of the errors will appear with the last one on top. If you go out of the error list it will be cleared. See the list of errors in the sub folders.


Error List 


2018-12-14 15:52:30:409		6	Emergency engine shutdown
2018-12-14 15:52:24:896		11	Water hot/cold temperature limiter reached
2018-12-14 15:52:12:127		8	Economy fuel cut-out
2018-12-14 15:52:08:508		9	RPM limiter reached
2018-12-14 15:52:07:049		3	Incorrect crank TDC slot
2018-12-14 15:52:07:037		1	Missing crank pulses
2018-12-14 15:52:05:261		1	Missing crank pulses
2018-12-14 15:52:05:232		1	Missing crank pulses
2018-12-14 15:51:56:132		1	Missing crank pulses

See the sub folders for the different error messages displayed on the Status bar:

Error Codes

The ECU software has Error, Warning and Information codes displayed in the Status tool bar at the bottom. These codes will help the tuner to find problems during startup and tuning, also to see if the ECU is functioning correctly. Some of the functions on the ECU will indicate to the tuner what is happening. He can then see if these functions are operating correctly.

 Count: 17 [Code 12 - Information: Launch limiter reached]

The codes are displayed at the right hand bottom corner. The code list  will display a list of accumulating codes so that the tuner can see what the codes were and in which order. The bottom indication will only show the last code. Also note that a code is only updated once, until it disappears and when it appears again the code will be logged again. This is to prevent the list from being too long. This does not apply to the angle sensor error codes during cranking. They will increment the counter as each one occurs.

Press the "C" key to clear the error codes. This is handy as you will not be able to see if the code is still present or if it was only listed once.

Note: If you crank an engine and it does not start, there will be one error code, error code 6 for **Emergency Engine Shutdown**. This is normal and not actually an error. The ECU was expecting more trigger pulses but pulses were stopped. Therefore, the ECU goes into a safe shutdown of coils and injectors etc. A tip, press C then crank the engine. There should be no error and it will read 200 RPM's on the rev counter until the key is released.

The **blue** codes are for crank, cam and other sensor related errors. The **red** codes are warnings like over temperature etc. The **green** codes are for information of functions that were activated. The colors are only for explanation in this document.


The following list explains the different error codes

- 1 - Missing crank pulses** – The crank sensor senses too little teeth per revolution
- 2 - Too many crank pulses or spikes** – The crank sensor senses too many teeth per revolution
- 3 - Incorrect crank TDC slot** – The crank sensor did not sense a TDC slot. (Maybe incorrect wiring)
- 4 - Missing TDC pulse** – The TDC pulse is not present
- 5 - Missing home pulse** – The Home pulse is not present
- 6 - Emergency engine shutdown** – Safe shutdown of engine due to lack of or incorrect signals
- 7 - Fuel pressure safety cut-out** – The fuel pressure sensor low limit has been reached
- 8 - Economy fuel cut-out** – The fuel economy cut is implemented
- 9 - RPM limiter reached** – The engine RPM limiter has been exceeded
- 10 - Max boost limiter reached** – The boost pressure limit has been exceeded
- 11 - Water hot/cold temperature limiter reached** – The water temperature limit has been exceeded
- 12 - Launch limiter reached** – The launch limit RPM has been exceeded
- 13 - Lambda control limits reached** – The lambda control limit has been reached
- 14 - Battery low voltage limit reached** – The battery voltage falls below a critical limit
- 15 - Selection refreshed. Confirm driver placement** – The ECU changed driver output configurations
- 16 - Timing retarded** – Ignition timing is retarded during an automatic transmission shift procedure
- 17 - Flood control injector cut-out** – Fuel is cut by injectors during cranking when the throttle is fully opened
- 18 - Flat-shift activated** – Ignition or fuel is cut for a moment to enhance gearshift for racing engines
- 19 - Ignition power switched off** – Ignition key power is switched off
- 20 - Sponsor counter depleted** – The sponsor counter is depleted for sponsored ECU's
- 21 - Anti-Lag activated** – Anti-Lag is activated on the Launch features
- 22 - Hardware Class don't support this feature** – Incorrect firmware loaded
- 23 - Speed Limit Reached** – Speed Limit was exceeded
- 24 - Bootloader Not Present** – This indicates if the BootLoader firmware was not loaded in the newer products
- 25 - Overcharge Limit Reached** – This error will come when the charge time plus graph times exceed the maximum charge times
- 26 - Test Mode is Selected** – This is used for calibrating TxW firmware
- 27 - Map was Reloaded** – This indicates that a Ma was reloaded from memory and installed in RAM to be used.
- 28 - Map Sensor Error** – This indicates MAP Sensor failure
- 29 - TPS Sensor Failure** – This indicates TPS Sensor failure
- 30 - Lambda Sensor Failure** – This indicates Lambda Sensor failure

- 31 - Water Temperature Sensor Failure** – This indicate Water Temperature Sensor failure
- 32 - Air Temperature Sensor Failure** – This indicate Air Temperature Sensor failure
- 33 - Altitude Sensor Failure** – This indicate Altitude Sensor failure
- 34 - Fuel Pressure Sensor Failure** – This indicate Fuel Pressure Sensor failure
- 35 - Potentiometer Sensor Failure** – This indicate Potentiometer Sensor failure
- 36 - Micro Fuel Activated** – This indicate that the Micro Fuel or Dual injector control were activated.

Selection Refreshed

This feature is initiated by the firmware to force the software to refresh its database. It happens when the tuner makes selections that are not legal for that specific firmware or when GP outputs are re-arranged by the features. The software will refresh and change the setting of the tuner to a safe level or disable other features. The messages below will then appear:



When you see this then you must go through the setup and see which devices have been changed and set them accordingly.