

8 Cyl 2 Coil Dizzy														
Wire Colors			Software Selectable			Orion2 ECU Layout			Software Selectable			Wire Colors		
			Sim	Pr 3	Priority2	Priority1				Priority1	Priority2	Pr 3	Sim	
	E24	E22	leds				P1 - 12 Way Input						leds	E22
	Green	Green					Water Temp	7	1	Air Temp				Yellow
	Red	Red					Lambda	8	2	TPS				Blue
	Red	Red					.+5 Volt Out	9	3	MAP				Blue
	Red	Red					.+12 Volt Ign	10	4	GND				Black
	N/C	Yellow					TDC Sensor	11	5	TDC Power				Blue
	Blue	Green					Crank Sensor	12	6	Crank Power				Red
								Internal	3Bar Alt Sensor	Altitude Sensor	Map Sensor			
							P2 - 10 Way Output							
E33	E32	E31												E31
Black/Red	Black/Red	Black/Red	N5			Basic Coil Drv 1	Coil Negative 1	6	1	Coil Negative 2	Basic Coil Drv 2		N6	Black/Purple
Black/Brown	N/C	Black/Brown	N7				Coil Negative 3	7	2	Coil Negative 4			N8	Black/Orange
Black/Yellow	Black/Yellow	Black/Yellow	N2	GP2		Inj Drv 2	Negative 2	8	3	Negative 1	Inj Drv 1		GP1	N1
Green	Green	Green	RPM			RPM Out	Negative 4	9	4	Negative 3	Relay Out			Relay
Blue/White	Blue/White	Blue/White	N4	GP4		Inj Drv 4	Negative 6	10	5	Negative 5	Inj Drv 3		GP3	N3
							P3 - 8 Way Output							
		E36												E36
		Red/White	P1	GP5	Idle Vlave		Positive 1	5	1	Positive 2		Micro Fuel	GP6	P2
		Red/Orange	P3	GP7	Cam 1		Positive 3	6	2	Positive 4		Cam 2	GP8	P4
		Red					.+12 Volt In	7	3	.+12 Volt In				Red
		White	GP1	GP9	Anti-Lag		Coil Negative 5	8	4	Coil Negative 6			GP10	GP2
							P4 - 4 Way Serial							
							SDA	3	1	SCL				
							.+5 Volt Out	4	2	GND				
							6 Way USB							
	P05-P3	USB					Tuning Pot	4	1	Dual Map Sw				USB
	Green	N/C					Receive	5	2	Transmit				N/C
	Yellow	Yellow					.+5 Volt Out	6	3	GND				Green
	Red	Red												Blue

Note!! Coil and Injector numbers used here are firing phases from the ECU. It is not the firing order on your engine.
Refer to the drawings for Phase to firing order comparison.

Negative 1 to 6 = Negative drivers 41 Volt 19 Amp Drivers

Positive 1 to 4 = Positive Drivers 12 Volt 6 Amp current limit drivers

Coil Negative 1 to 6 = Negative Coil Drivers for Basic Coils 500 Volt 18 Amp Drivers

Tuning Pot and Coil Driver 6 share the same Micro Connection. Selection with Jumper J6 on board

Dual Map Switch and Coil Negative 5 share the same Micro Connection. Selection with Jumper J6 on board

An optional 3 Bar map sensor can be soldered onto board. It can be used as Altitude or MAP sensor. For an internal MAP sensor you need to make a hole in the lid for the pipe to come through.

Basic Coil = Coil without driver - 0.5 to 0.9 Ohm Primary winding - Charges with earth signal and discharges with open signal

Smart Coil = Coil with Built in driver - Charges with positive signal and discharges with earth signal which is provided by the driver and a pull down resistor

If you use the 3 Bar onboard sensor for MAP then you must use a 2.5 Bar external sensor for Altitude.

Coil Phaze	Fire Order Ex. 1 8 4 3 6 5 7
	Wasted Spark
Coil Drv 1	1 - 4 - 6 - 7
Coil Drv 2	8 - 3 - 5 - 2

Inject Phaze	Fire Order Ex. 1 8 4 3 6 5 7 2
	Split Seq
Inj Drv 1	1 - 6
Inj Drv 2	8 - 5
Inj Drv 3	4 - 7
Inj Drv 4	3 - 2