Callisto 6Cyl 3x Injector Drivers Hight Imp

Last Changed: 05/07/2025 Harness: E62-P2

Note! This drawing is used with Smart Coil Setup



Software Settings				
Injection Type	Split Se	eq 1x Inj Per Driver	¢	
Injector Driver Outputs				
Injector Driver Out	put 1	HV Negative Output 1		
Injector Driver Out	put 2	HV Negative Output 2		
Injector Driver Out	put 3	HV Negative Output 3		
Injector Driver Out	put 4	HV Negative Output 4		
Injector Driver Out	put 5	HV Negative Output 5		
Injector Driver Out	put 6	HV Negative Output 6		

S

Note!: The software shows 6 drivers but only 3 drivers may be installed. Then connect 2 Injectors per ECU Driver



Write your firing order from left to right in the blocks above marked with an alphabetical letter. Then write the corresponding number on the corresponding injector with the same alphabetical letter in the drawing below. Now connect your injector number to the corresponding colour wire.

Note: The order of the injectors will differ on their placing on the engine, as long as it is connected to the same colour wire as this illustration. Two injectors in three pairs will have the same colour wire because they are pulsed together. Connect them as such.