

8Cyl Lexus 1UZ 2x Basic Coils

<u>Last Changed:</u> 29/04/2024 <u>Preferred Harness:</u> E41 <u>Other Harnesses:</u> E31,E40

Note: The order of the coils are defined by the firmware. Two Distributors with one coil each.





Coil Driver Trigger Combination

Basic Coil – Use Coil Negative Drivers

Coil Driver Outputs

Coil Driver Output 1 Coil Negative 1

Coil Driver Output 2 Coil Negative 2

٧

Software Settings

Coil Combination 4

Dual Distributor