




Pluto Fan Controller Ver 1.1

Last Changed: 26/10/2024


Jumper Settings



To Program the unit place J1 and J2 in the up position.



Harness Pin View




Connector Pinouts

- 1.
- 2.
3. Blue - Water Tap In
4. Black - GND
- 5.
- 6.
7. Red - Water Standalone
- 8.
- 9.
10. Orange - +12V Ign Input
11. Red - Aircon Override
12. Red - Manual Override

Connector Pinouts

- 1.
- 2.
- 3.
4. Black/Orange - GP3
5. Black/White - GP1 PWM Fan
- 6.
- 7.
- 8.
9. Black/Brown - GP4
10. Black/Yellow - GP2

Connector Pinouts



Led's Functions
Yellow - Power
Green - PWM Fan Active
Red - Override Active

