

<u>Last Changed:</u> 28/08/2019 Harness: MTWX02-2

Magnetic RPM Sensor Tap-In Jumper 2 Open J1 & J2 ORed2 Reference Volts Signal OEM ECU/TCU RPM Sensor -RPM Sensor + Ρ4 ORed1 Green RPM In OGreen2 OGreen1 OYellow Green RPM In

Hall or Optic or Tacho RPM Sensor Tap-In







<u>Last Changed:</u> 28/08/2019 Harness: MTWX02-2

Magnetic RPM Sensor Tap-In Jumper 2 Open J1 & J2 ORed2 Reference Volts Signal OEM ECU/TCU RPM Sensor -RPM Sensor + Ρ4 ORed1 Green RPM In OGreen2 OGreen1 OYellow Green RPM In

Hall or Optic or Tacho RPM Sensor Tap-In







<u>Last Changed:</u> 28/08/2019 Harness: MTWX02-2

Magnetic RPM Sensor Tap-In Jumper 2 Open J1 & J2 ORed2 Reference Volts Signal OEM ECU/TCU RPM Sensor -RPM Sensor + Ρ4 ORed1 Green RPM In OGreen2 OGreen1 OYellow Green RPM In

Hall or Optic or Tacho RPM Sensor Tap-In







<u>Last Changed:</u> 28/08/2019 Harness: MTWX02-2

Magnetic RPM Sensor Tap-In Jumper 2 Open J1 & J2 ORed2 Reference Volts Signal OEM ECU/TCU RPM Sensor -RPM Sensor + Ρ4 ORed1 Green RPM In OGreen2 OGreen1 OYellow Green RPM In

Hall or Optic or Tacho RPM Sensor Tap-In





<u>Last Changed:</u> 28/08/2019 Harness: MTWX02-2

Magnetic RPM Sensor Tap-In Jumper 2 Open J1 & J2 ORed2 Reference Volts Signal OEM ECU/TCU RPM Sensor -RPM Sensor + Ρ4 ORed1 Green RPM In OGreen2 OGreen1 OYellow Green RPM In

Hall or Optic or Tacho RPM Sensor Tap-In

